# JVE


# SERVICE MANUAL

# **COLOUR VIDEO MONITOR**

**TM-1000PS** 

**BASIC CHASSIS** 

KII



# **CONTENTS**

SPECIFICATIONS	•	. :	2
SAFETY PRECAUTIONS		. (	3
OPERATING INSTRUCTIONS			4
SPECIFIC SERVICE INSTRUCTIONS		. 8	E
SERVICE ADJUSTMENTS		1	1
PARTS LIST		2	1
SCHEMATIC DIAGRAM(APPENDED)	1	~(1	Ì

# **SPECIFICATIONS**

Iter	n	Content
Dimensions		22.3cm(W) × 32.74cm(D) × 22.7cm(H)
Weight		9kg
Color system		PAL/SECAM system
Power input	* *	AC 220 - 240V 50/60Hz , DC 12V
Power consum	ntion	AC 0.39A , DC 3A
Picture Tube	, puo	10" (measured diagonally), 90° deflection, in-Line gun, data grade tinted CRT
		dot pitch 0.47mm
Caroon Siza		173mm(W)×137mm(H)
Screen Size Scanning frequency		(H) 15.625KHz
Scamming med	ac,	(V) 50Hz
High voltage		21kV(at zero beam current)
Horizontal res	olution	More than 300 lines
Speaker		8cm round(8 $\Omega$ )×1
Audio output		1W
Audio odipai		
INPUT A		
	VIDEO	BNC ×2(IN/OUT), Bridged connection is possible.
		VS 1Vp-p, 75Ω, negative
		A termination switch is provided.(75 $\Omega$ /OPEN)
	AUDIO	RCA pin connector × 2(IN/OUT), Bridged connection is possible.
		390mVrms, High impedance
INPUT B	VIDEO	BNC×2(IN/OUT), Bridged connection is possible.
/EXT SYNC		VS 1Vp-p, $75\Omega$ , negative
	/SYNC	SYNC 1 - 4Vp-p, $75\Omega$ , negative
		A termination switch is provided.(75Ω/OPEN)
		A terrimation switch is provided. (70-1110)
Y/C INPUT		
1	Y/C	7-pin connector × 2(IN/OUT), Bridged connection is possible.
		Y 1Vp-p, 75Ω, negative
]		C 0.3Vp-p(burst), 75Ω
1		A termination switch is provided.(75Ω/OPEN)
	AUDIO	RCA pin connector × 2(IN/OUT), Bridged connection is possible.
		390mVrms, High impedance
ACCESSORY	1	Power cord(approx. 2m) × 1
		DIV 40F/DAOV MOUNT ADARTOD)
OPTION		RK-10E(RACK MOUNT ADAPTOR)

Design & specification subject to change without notice.

# SAFETY PRECAUTIONS

- The design of this product contains special hardware, many circuits and components specially for safety purposes.
   For continued protection, no changes should be made to the original design unless authorized in writing by the manufacturer. Replacement parts must be identical to those used in the original circuits. Service should be performed by qualified per-
- Alterations of the design or circuitry of the products should not be made. Any design alterations or additions will void the manufacturer's warranty and will further relieve the manufacturer of responsibility for personal injury or property damage resulting therefrom.

sonnel only.

- 3. Many electrical and mechanical parts in the products have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in the parts list of Service manual. Electrical components having such features are identified by shading on the schematics and by (A) on the parts list in Service manual. The use of a substitute replacement which does not have the same safety characteristics as the recommended replacement part shown in the parts list of Service manual many create shock, fire, or other hazards.
- Don't short between the LIVE side ground and NEU-TRAL side grounding or EARTH side ground when repairing.
  - Some model's power circuit is partly different in the GND. The difference of the GND is shown by the LIVE ( \( \\_ \) ) side GND, the NEUTRAL( \( \\_ \) ) side GND and EARTH ( \( \\_ \) ) side GND. Don't short between the LIVE side GND and NEUTRAL side GND or EARTH side GND and never measure with a measuring apparatus (oscilloscope etc.) the LIVE side GND and NEUTRAL side GND or EARTH side GND at the same time. If above note will not be kept, a fuse or any parts will be broken.
- If any repair has been made to the chassis, it is recommended that the B1 setting should be checked or adjusted (See AD-JUSTMENT OF B1 POWER SUPPLY).
- 6. The high voltage applied to the picture tube must conform with that specified in Service manual. Excessive high voltage can cause an increase in X-Ray emission, arcing and possible component damage, therefore operation under excessive high voltage conditions should be kept to a minimum, or should be prevented. If severe arcing occurs, remove the AC power immediately and determine the cause by visual inspection (incorrect installation, cracked or melted high voltage harness, poor soldering, etc.). To maintain the proper minimum level of soft X-Ray emission, components in the high voltage circuitry including the picture tube must be the exact replacements or alternatives approvided by the manufacturer of the complete product.
- 7. Do not check high voltage by drawing an arc. Use a high voltage meter or a high voltage probe with a VTVM. Discharge the picture tube before attempting meter connection, by connecting a clip lead to the ground frame and connecting the other end of the lead through a 10kΩ 2W resistor to the anode button.
- 8. When service is required, observe the original lead dress. Extra precaution should be given to assure correct lead dress in the high voltage circuit area. Where a short circuit has occurred, those components that indicate evidence of overheating should be replaced. Always use the manufacturer's replacement components.

## 9. Isolation Check (Safety for Electrical Shock Hazard)

After re-assembling the product, always perform an isolation check on the exposed metal parts of the cabinet (antenna terminals, video/audio input and output terminals, Control knobs, metal cabinet, screwheads, earphone jack, control shafts, etc.) to be sure the product is safe to operate without danger of electrical shock.

#### (1) Dielectric Strength Test

The isolation between the AC primary circuit and all metal parts exposed to the user, particularly any exposed metal part having a return path to the chassis should withstand a voltage of 3000V AC (r.m.s.) for a period of one second.

(.... Withstand a voltage of 1100V AC (r.m.s.) to an appliance rated up to 120V, and 3000V AC (r.m.s.) to an appliance rated 200V or more, for a period of one second.)

This method of test requires a test equipment not generally found in the service trade.

#### (2) Leakage Current Check

Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.) Using a "Leakage Current Tester", measure the leakage current from each exposed metal part of the cabinet, particularly any exposed metal part having a return path to the chassis, to a known good earth ground (water pipe, etc.). Any leakage current must not exceed 0.5mA AC (r.m.s.).

#### Alternate Check Method

Plug the AC line cord directly into the AC outlet (do not use a line isolation transformer during this check.). Use an AC voltmeter having 1,000 ohms per volt or more sensitivity in the following manner. Connect a 1,500Ω 10W resistor paralleled by a 0.15μF AC-type capacitor between an exposed metal part and a known good earth ground (water pipe, etc.). Measure the AC voltage across the resistor with the AC voltmeter. Move the resistor connection to each exposed metal part, particularly any exposed metal part having a return path to the chassis, and measure the AC voltage across the resistor. Now, reverse the plug in the AC outlet and repeat each measurement, Any voltage measured must not exceed 0.35V AC (r.m.s.). This corresponds to 0.5mA AC (r.m.s.).





Fig.A

# **OPERATING INSTRUCTIONS**

# CONTROLS AND CONNECTORS



#### **Front Panel**

#### V. HOLD control

Turn to adjust the vertical synchronization of the picture.

#### VOLUME control

Turn clockwise to make the sound louder. Counterclockwise to make it softer.

#### Picture controls

Use to optimize the picture. The centre click position of each control is its standard setting. This standard setting can be varied (preset) by turning the SUB control screws at the side of the controls. Use a screwdriver to turn the SUB controls.

#### CHROMA control

Turn to adjust the colour density of the picture to your preference.

#### BRIGHT control

Turn to adjust the picture brightness to your preference.

#### CONTRAST control

Turn to adjust the picture contrast to your preference.

#### Input select switches

Press to select the video signals input to the rear connectors. (Selecting the signals)

 Set the switch on the upper side to VIDEO or Y/C position.

VIDEO ( ... ) : When monitoring a composite video

(via the INPUT A or INPUT B connector on the rear panel)

Y/C (-) : When monitoring Y/C separate video signals

(via the Y/C INPUT connector on the rear panel)

(2) While setting the upper switch to "VIDEO", set the switch on the lower side to A or B position.

A ( ): When monitoring a signal via the IN-PUT A connector

B ( - ) : When monitoring a signal via the IN-PUT B connector

#### System switch

Switches the colour system when a video signal is input.

PAL ( ... ) : For PAL colour system SECAM ( ... ) : For SECAM colour system

#### **6** EXT SYNC switch

Switches the sync signal.

( ■ ): External sync (using sync signal input to the rear panel's INPUT B/EXT SYNC connector)

( - ): Internal sync

#### PULSE CROSS switch

To check the retrace period (sync signal) by delaying the phase of the input signal.

OFF (♣): For normal picture
ON (♣): For retrace period
check display

#### COLOUR OFF switch

Switches picture between colour and monochrome for checking white balance, etc.

( = ) : For a colour picture

( - ) : For a monochrome picture

#### **9** UNDER SCAN switch

Press to switch the scanning size on the screen.

( ): for overscanning

( - ) : for underscanning

#### **10** BLUE CHECK switch


Switches the picture between normal and monochrome blue, for checking and adjusting the CHROMA.

( ... ) : Normal picture


( — ) : Monochrome blue picture Adjusting procedure

 Input the colour bar signal to display a monochrome blue picture.

(2) Turn the CHROMA control so that all blue bars have the same density and brightness.



## (Rear Panel)



#### Rear Panel

#### Power input connectors

Connect the AC IN connector to an AC outlet with the provided power cord. Connect the DC IN 12 V connector to a DC 12 V power source.

#### (B) INPUT A connectors/Termination switch

Input connectors for composite video and audio signals and output connectors for bridge-connected signals.

IN : When inputting a signal OUT : For bridged connection Setting the termination switch

75  $\Omega$ : When there is only an input signal

OPEN: For bridged connection

#### INPUT B/EXT SYNC connector/Termination switch Input connector for a composite video or sync signal. The

IN and OUT connectors are bridge-connected.

IN : When inputting signals
OUT : For bridged connection

Setting the termination switch 75 $\Omega$ : When there are only input signals

OPEN : For bridged connection

#### INPUT Y/C connectors/Termination switch

Input connectors for Y/C separate video and audio signals and output connectors for bridge-connected signals.

IN : When inputting signals
OUT : For bridged connection
Setting the termination switch

75  $\Omega$ : When there are only input signals

**OPEN**: For bridged connection

Caution: These connectors can only be connected to the Y/C443 connectors of the VTR; they cannot be connected to the other dubbing connectors (DUB,

Y/C629, Y/C633, and etc.)

#### **®** SET UP switch


Do not reset this switch. It is for service personnel only.


#### AFC switch

Switches the AFC time constant of the horizontal sync circuitry to correct the skewed portion of the picture.

FAST : Fast mode (Smaller time constant)


NORMAL : Normal mode





## GOVIVE OF IONS

- Be sure to disconnect the power plug from the power source before connecting to other equipment.
- Also refer to the instruction manual of the equipment to be connected.



## SAFETY PRECAUTIONS

In order to prevent any fatal accidents caused by misoperation or mishandling of the monitor, be fully aware of all the following precautions.

#### **WARNINGS**

To prevent fire or shock hazard, do not expose this monitor to rain or moisture.


Dangerous high voltages are present inside the unit. Do not remove the back cover of the cabinet.

When servicing the monitor, contact qualified service personnel. Never try to service it yourself.

Improper operations, in particular alteration of high voltage or changing the type of tube may result in x-ray emission of considerable dose. A unit altered in such a way no longer meets the standards of certification, and must therefore no longer be operated.

The AC outlet should be located near to the monitor and easily accessible.

Connection diagram for power supply



Disconnection from power supply:

- 1) Pull out AC cable and
- 2) Disconnect battery plug.

#### **PRECAUTIONS**


- Use only the power source specified on the rating label located on rear of the cabinet.
- When not using this unit for a long period of time, or when cleaning it, be sure to disconnect the power plug from the AC outlet.
- Do not allow anything to rest on the power cord. And do not locate this unit where people will tread on the cord.
- Do not overload wall outlets or power cords as this can result in a fire or electric shock.
- Avoid using this unit under the following conditions:
  - in extremely hot, cold or humid places,
  - in dusty places,
  - near appliances generating strong magnetic fields,
  - in places subject to direct sunlight, and
- in badly ventilated places.
- Do not cover the ventilation slots while in operation as this could obstruct the required ventilation.
- When dust accumulates on the screen surface, clean with a soft cloth.
- Unplug this unit from the AC outlet and refer servicing to qualified service personnel under the following conditions:
  - When the power cord is frayed or plug is damaged.
  - If liquid has been spilled into the unit.
  - If the unit does not operate normally following the operating instructions.
  - If the unit has been dropped or the cabinet has been damaged.
  - When the unit exhibits a distinct change in performance
- Do not attempt to service this unit yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Always refer servicing to qualified service personnel.
- When replacement parts are required, have the service personnel verify in writing that the replacement parts he uses have the same safety characteristics as the original parts.
   Use of manufacturer's specified replacement parts can prevent fire, shock, or other hazards.
- Upon completion of any servicing or repair to this unit, please ask the service personnel to perform the safety check described in the manufacturer's service literature.
- When this unit reaches the end of its useful life, improper disposal could result in a picture tube implosion. Ask qualified service personnel to dispose of this unit.

# SPECIFIC SERVICE INSTRUCTIONS

## **DISASSEMBLY PROCEDURE**

## 1. Removal of the TOP COVER

- (1) Remove the 2 screws (A) shown in Fig. 1.
- (2) Remove the 3 screws (B).
- (3) Slightly pull backward as shown by the arrow and remove the top cover.




## 2. Removal of the REAR COVER

- (1) Remove the top cover.
- (2) Remove the 2 screws © shown in Fig. 2.
- (3) Loosen the 3 screws D.
- (4) Slightly slide the rear cover in the direction of the arrow and remove it.

#### the SIGNAL PC BOARD 3. Removal of **ASSEMBLY**

- (1) Remove the 3 screws © shown in Fig. 3.
- (2) Open the signal PC board assembly towards yourself as shown by the arrow.
- (3) Grasp at the position of arrows  ${\color{black} \mathbb O}$  and pull in the direction of arrow 2 to remove the signal PC board assembly. (Removing the hinge connectors one by one facilitates the removal.) (Fig. 4)






Fig. 4




Fig. 3

### 4. Checking the DEF. PC BOARD ASSEMBLY

- (1) Place the set on its side as shown in Fig. 5. At this time, in order not to cause scratches on the outer cover, place a cloth under the set.
- (2) Remove the 6 screws (2) and remove the bottom lid.




Fig. 5

# 5. Removal of the DEF. PC BOARD ASSEMBLY

- Remove the 3 screws © of Fig. 6 to remove the AV terminal.
- (2) Remove the screw (1) shown in Fig. 7.
- (3) Remove the CRT SOCKET PC BOARD, wires of the DEF. YOKE and the HVT and other wires as well.
- (4) Pull the DEF. PC BOARD ASSEMBLY toward you and remove it. (When replacing the DEF. PC BOARD ASSEMBLY to its original position, confirm that it is connected to the connector of the CONTROL PC BOARD ASSEMBLY.)





Fig. 6



# 6. Removal of the POWER SUPPLY ASSEMBLY

- (1) Remove the 2 screws ① shown in Fig. 8.
- (2) Slight lift up the AC input side of the POWER SUPPLY ASSEMBLY and slide it in the direction of the arrow to remove it.




Fig. 8

## 7. Removal of the FRONT PANEL

- (1) Remove the 4 screws ① shown in Fig. 9.
- (2) Remove the front panel in the direction of the arrow.





Fig. 9

## 8. Removal of the CRT

(1) After removing the front panel, remove the 4 nuts attaching the CRT.

# 9. Removal of the CONTROL PC BOARD ASSEMBLY

(1) After removing the front panel, remove the 2 screws ® shown in Fig. 10.



## **•WIRE CLAMPING AND CABLE TIES**

Be sure to clamp the wire.

Never remove the cable tie used for tying the wires together. Should it be inadvertently removed, be sure to tie the wires with a new cable tie.

# SERVICE ADJUSTMENTS

## PRIOR TO STARTING **ADJUSTMENT**

- Perform sufficient warm-up of the TV set and testers. (for 30 minutes or more).
- Unless specified otherwise specially in [ADJUSTING STEP] given below, perform adjustment after setting the switches and VRs on the front panel to the following positions:

UNDER SCAN : OFF(OVER SCAN)

BLUE CHECK

: OFF

PULSE CROSS : OFF

COLOUR OFF

: OFF

SYSTEM SW EXT SYNC

: PAL : INT

Y/C

: OFF(VIDEO)

A/B

: VIDEO A

CONTRAST

BRIGHT

: CLICK position

: CLICK position

CHROMA : CLICK position VOLUME : MIN. position

Regarding the list of the layout of adjusted parts, refer to [ALIGNMENT LOCATION] in [SCHEMATIC DIAGRAM].

## TOOLS AND FIXTURES FOR **ADJUSTMENT**

- DC voltmeter or digital voltmeter
- Oscilloscope
- Pattern generator (PAL/SECAM)
  - · The signal should be input to INPUT A(VIDEO).
- TV Color analyzer
  - · Adjustment is possible without it. If available, however, further accurate adjustment is possible.
- Short jumper
- De-magnetizer
- DC power supply (12V 5A)

## **ADJUSTING STEP**

#### POWER PC BOARD ASS'Y

Item	Measuring instrument	Test point	Adjustment part	Description
Adjustment of B1 VOLTAGE (B1 POWER SUPPLY)	PATTERN GENERATOR  DC VOLTMETER or DIGITAL VOLTMETER	TP-91 (DEF. PC BOARD) TP-E( <del>               </del>	R919 (B1 ADJUSTMENT)	<ol> <li>Input the black field pattern signal.</li> <li>Adjust the B1 ADJUSTMENT VR (R919) so that the voltage between TP-91 (DEF. PC BOARD) and TP-E ( (-)-r) becomes DC 30V.</li> <li>Confirm that the B1 voltage scarcely changes even when the input signal has been changed.</li> </ol>
Adjustment of BATTERY PROTECTOR CIRCUIT	PATTERN GENERATOR  DC VOLTMETER or DIGITAL VOLTMETER  DC POWER SUPPLY  (B CONNECTOR)		R925 (BATTERY PROTECTOR VR)	<ol> <li>Input the black field pattern signal.</li> <li>Turn the BATTERY PROTECTOR VR (R925) as far as possible to the right.</li> <li>Apply 12V DC to the DC 12V terminal of the set.</li> <li>Set the power switch of the set to ON and confirm that the black field pattern appears (the power indicator lights in green).</li> <li>Set the DC input voltage for the set to 10.5V ±0.1V DC.</li> <li>Slowly turn the BATTERY PROTECTOR VR (R925) to the left side, and stop turning when the power indicator has turned from green through orange to red. At this time, the operation of the set will stop.</li> <li>Set the power switch of the set to OFF. (The</li> </ol>
POWER PC	25		PC BOARD	protection circuit will be set.)  8. Set the DC input voltage of the set to the regular voltage of 12V.  9. Set the power switch of the set to ON again.  10.Confirm that the operation of the set is normal.  11.Gradually lower the DC input voltage of the set from 12V, and when it becomes 10.5V ±0.2V, confirm that the power indicator lights in red.

## SIGNAL PC BOARD ASS'Y

ltem	Measuring instrument	Test point	Adjustment part	Description
Adjustment of COLOR SYNCHRONISM	PATTERN GENERATOR OSCILLOSCOPE SHORT JUMPER	TP-51A TP-51B TP-43B TP-E()	C309	<ol> <li>Turn the SYSTEM SW to PAL.</li> <li>Input the PAL color bar signal.</li> <li>Connect TP-51A and TP-51B with a short jumper.</li> <li>Connect TP-43B and TP-E ( ) with a short jumper.</li> <li>Adjust the COLOR SYNC. (C309) to a position where the color changes from a striped pattern to a color bar and remains at a standstill.</li> <li>Remove the connected short jumper.</li> <li>Make sure that the color synchronism is not collapsed and instantaneously led in when returned to the color bar signal again after changing the input select switch.</li> </ol>
Adjustment of PAL CHROMA	PATTERN GENERATOR OSCILLOSCOPE	TP-48 TP-49	R338 (DL LEVEL) C332 C341 C328 C309	<ol> <li>Turn the SYSTEM SW to PAL.</li> <li>Input the PAL color bar signal.</li> <li>Connect the oscilloscope to TP-48 and TP-49,and plot the X-Y coordinates.</li> <li>Adjust with DL LEVEL VR (R338) and C332 C341 so that the waveforms are the shapes shown from A to B in the chart below.</li> </ol>
	TP-49  TP-70 TP-49  R814  R816  TP-Y  SIGNAL PC BC	R338 R351 TF C341 C332 C328		5. When it is not possible to adjust with the R338 C332 C341, adjust with C328. 6. Input the half color bar. 7. Adjust with C309 so that the color at the center section under the color bar is at minimum.

## SIGNAL PC BOARD ASS'Y

Item	Measuring instrument	Test point	Adjustment part	Description
Adjustment of NOCTH CIRCUIT	PATTERN GENERATOR OSCILLOSCOPE	ТР-Ү	C215	Turn the SYSTEM SW to SECAM.     Input the SECAM color bar signal.     Connect the oscilloscope between TP-Y and TP-E.     In case the waveform can be expanded by the oscilloscope, expand the waveform to allow easy
	Minimize the CHRO	MA component  of waveform		adjustment.  4. Adjust the C215 so that the CHROMA component becomes minimum.
Adjustment of H PULSE	PATTERN GENERATOR OSCILLOSCOPE	TP-Y TP-70	R814 R816(P/C)	<ol> <li>Turn the SYSTEM SW to PAL.</li> <li>Input the PAL color bar signal.</li> <li>Connect the oscilloscope to TP-Y and TP-70 Pin, set to the dual-trace and increase the SYNC section.</li> </ol>
	Y SYNC H PULSE Coi	ncidence		<ul> <li>4. Adjust with R814 so that the SYNC forward line of the Y signal and the start of the H PULSE coincide.</li> <li>5. Confirm that the waveform phase dose not slip even when the pulse cross SW is pressed.</li> <li>6. If the phase slips,use R816 to adjust so that the H PULSE dose not come to the left side (leading phase) of the SYNC of Y signal.</li> </ul>

## SECAM MODULE CIRCUIT

item	Measuring instrument	Test point	Adjustment part	Description	
Adjustment of SECAM CHROMA	PATTERN GENERATOR OSCILLOSCOPE DC VOLTMETER	TP-301 TP-302	T301S (BELL TRANSF.) T302B (CW TRANSF.)	<ol> <li>Turn the SYSTEM SW to SECAM.</li> <li>Input the SECAM color bar signal.</li> <li>Connect an oscilloscope to pin (f) (or TP-301) or IC301.</li> <li>Adjust the BELL TRANSF. (T301S) for flat waveform as altered to figure (B) from (A).</li> </ol>	
	T304 T305 DISCRI DISCRI TRANSF TRAN  SECAM MODULE PCB AS	TP-301 T301S BELL TRANSF	T304 T305 (DISCRI TRANSF.)	5. Connect a voltmeter to pin (1) (or TP-302) of IC301. 6. Adjust CW TRANSF. (T302B) for minimum DC voltage. 7. Adjust the DISCRI TRANSF. (T304 & T305) until colors are eliminated from the black-and-white (or white) sections of colour bars on the screen.	

## CONTROL PC BOARD ASS'Y

ltem	Measuring instrument	Test point	Adjustment part	Description
Adjustment of SUB BRIGHT	PATTERN GENERATOR	Vertical flyback	R109 (SUB BRIGHT)	<ul> <li>Continue running for 30 minutes or more.</li> <li>Set the CONTRAST and BRIGHT VRs on the front panel to the clicking position.</li> <li>Input the cross hatch signal.</li> <li>Turn the V. HOLD VR to display the vertical flyback time and let it remain at a standstill.</li> <li>Adjust the SUB BRIGHT VR (R109) in front of the position where the vertical flyback time becomes black (In this case, be careful so that it will not become too bright).</li> <li>Adjust the vertical synchronism with the V. HOLD VR.</li> </ul>
Adjustment of SUB CONTRAST	PATTERN GENERATOR OSCILLOSCOPE	TP-47B TP-E	R103 (SUB CONT.)	Set the CONTRAST and BRIGHT VRs on the front panel to the clicking position.  Input the cross hatch signal.  Connect the oscilloscope between TP-47B and TP-E on the CRT SOCKET PCB.  Adjust the SUB CONT. VR (R103) so that the voltage of the waveform becomes 28V <sub>B-W</sub> .

## CONTROL PC BOARD ASS'Y & SIGNAL PC BOARD ASS'Y

Item	Measuring instrument	Test point	Adjustment part	Description
Adjustment of SUB CHROMA	PATTERN GENERATOR OSCILLOSCOPE Y Cy G Mg R	TP-47B TP-E	CONTROL PC BOARD ASS'Y R121 (SUB CHROMA)  SIGNAL PC BOARD ASS'Y R351 (PAL SUB CHROMA)	<ul> <li>Turn the CHROMA VR on the front panel to the click position.</li> <li>1. Turn the SYSTEM SW to SECAM.</li> <li>2. Input the SECAM color bar signal.</li> <li>3. Connect TP-47B of the CRT SOCKET PCB to the oscilloscope.</li> <li>4. Turn SUB CHROMA (R121) to adjust the white and blue levels.</li> <li>5. Return the SYSTEM SW to PAL.</li> <li>6. Input the PAL color bar signal.</li> <li>7. Turn PAL SUB CHROMA (R351) to set the difference of white and blue to 0V.</li> </ul>

## DEF. PC BOARD ASS'Y

Item	Measuring instrument	Test point	Adjustment part	Description
Adjustment of FOCUS	PATTERN GENERATOR		FOCUS VR	Input the cross hatch signal.     Adjust the FOCUS VR to a position where the vertical and horizontal lines of cross hatch become
		Both the verti horizontal line be made thin	es should	thinnest and clearest.  Note: Be sure to perform final adjustment of the convergence after adjustment of focus, since the convergence will be changed whenever the focus has been adjusted.
Adjustment of HORIZONTAL HOLD	PATTERN GENERATOR SHORT JUMPER  TP-33 R526 TP-E  R433 TF  S501 R425 R427 R427 R427 R427 R427 R427 R427 R427	R550	R526 (H HOLD)	<ul> <li>Set the CONTRAST VR on the front panel to the clicking position.</li> <li>Input the color bar signal.</li> <li>Connect TP-33A and TP-E with a short jumper.</li> <li>Adjust the H. HOLD VR (R526) to a position where the image remains at a standstill without flowing horizontally.</li> <li>Namely, adjust the VR to an intermediate position where the image flows horizontally.</li> <li>Remove the connected short jumper.</li> <li>Make sure that the color synchronism is not collapsed and normal image appears instantaneously when returned to the color bar signal again after changing the input select switch.</li> </ul>

**DEF. PC BOARD ASS'Y** 

Item	Measuring instrument	Test point	Adjustment part	Description
Adjustment of H. WIDTH and H. CENTER	PATTERN GENERATOR		L502(H. WIDTH COIL) S501 (H CENTER) R550 (H POSITION)	<ol> <li>Input the monoscope signal or cross hatch signal.</li> <li>Select the OVER SCAN screen with the UNDER SCAN switch on the front panel.</li> <li>With the H. WIDTH COIL (L502) and H. CENTER switch (S501), perform adjustment so that 90% of monoscope pattern (cross hatch) is displayed on the screen.</li> <li>Select the UNDER SCAN screen with the UNDER SCAN switch on the front panel.</li> <li>In case the image is chipped off from the raster, adjust the H. POSITION VR (R550).</li> <li>Select the OVER SCAN screen with the UNDER SCAN switch on the front panel.</li> </ol>
	95%  95%  [OVER SCAN] screen  A = B  [UNDER SCAN] screen		R425(V.HEIGH T NORMAL)  R433(V.CENTE R)  R427(V.LIN.)  R426(V.HEIGH T UNDER)	<ol> <li>Input the monoscope signal or cross hatch signal.</li> <li>Select the OVER SCAN screen with the UNDER SCAN switch on the front panel.</li> <li>Roughly adjust the V. HEIGHT NORMAL VR (R425) so that nearly all the monoscope pattern (cross hatch) is displayed on the screen.</li> <li>With the V. HEIGHT NORMAL VR (R425) and V. CENTER VR (R433), perform adjustment so that 95% of the monoscope pattern (cross hatch) is displayed on the screen.</li> <li>While turning the V. LIN. VR (R427), adjust the vertical linearity.</li> <li>Repeat the Steps 3 - 5 as required.</li> <li>Select the UNDER SCAN screen with the UNDER SCAN switch on the front panel.</li> <li>Adjust the V. HEIGHT UNDER VR (R426) so that the vertical amplitude becomes A = B (making the vertical and horizontal diameter the same).</li> <li>Perform fine adjustment of the center and vertical linearity so that displacement of adjustment will not occur even if the SCAN switch on the front panel has been changed over.</li> <li>Select the OVER SCAN screen with the UNDER SCAN switch on the front panel.</li> </ol>

## CRT SOCKET PC BOARD ASS'Y

ltem	Measuring instrument	Test point	Adjustment part	Description
	PATTERN GENERATOR  R714 R713  704 R703 R723  TP-E TP-47E CRT SOCKET	•	R703 (R CUTOFF)  R713 (G CUTOFF)  R723 (B CUTOFF)  SCREEN VR	<ul> <li>Continue running for 10 minutes or more.</li> <li>1. Input the black field pattern signal.</li> <li>2. Turn the transverse one line SET UP switch (S204) on the rear surface over to the SET UP side.</li> <li>3. Turn the CUT OFF VRs (R703, R713 and R723) on the CRT SOCKET PCB fully in counterclockwise direction.</li> <li>4. While turning the SCREEN VR gradually in clockwise direction from full counterclockwise direction, search for the color appearing for the first time.</li> <li>5. Turn the CUT OFF VRs, with which the color has appeared first in the Step 4, slightly in clockwise direction.</li> <li>6. By turning the CUT OFF VRs for the other two colors in clockwise direction, adjust the intensity of the three shining colors so that the transverse single line look white.</li> <li>7. Return the transverse single line SET UP switch (S204) to the NORMAL side.</li> </ul>
Adjustment of WHITE BALANCE (DRIVE)	PATTERN GENERATOR		R704 (R DRIVE) R714 (G DRIVE)	<ul> <li>Continue running for 30 minutes or more.</li> <li>This adjustment should be performed after Adjustment of WHITE BALANCE (CUTOFF).</li> <li>Input the white field pattern signal.</li> <li>Adjust the R and G DRIVE VRs (R704 and R714) on the CRT SOCKET PCB to a position where the entire screen becomes white.</li> <li>While turning the CONTRAST VR and BRIGHT VR on the front panel, make sure that the white balance is attained.</li> </ul>
				<ul> <li>[In case monoscope signal and TV Color analyzer are available]</li> <li>1. Input the monoscope signal.</li> <li>2. The light receiving unit of the TV Color analyzer will measure the color temperature at the center of the screen.</li> <li>3. Adjust the CONTRAST VR, R and G DRIVE VRs (R704 and R714) on the CRT SOCKET PCB to a position where the TV Color analyzer indicates a specified value.</li> <li>Color temperature</li> </ul>

# ADJUSTING STEP OF COLOR TONE

## **ADJUSTMENT OF PURITY**

Adjustment Part	Description	Remarks
	PRIOR TO STARTING ADJUSTMENT:  1. Remove the wedge being inserted in between the deflecting yoke. At this time, clear the trace of the wedge.  2. Peel of the adhesive attaching the six magnets and magnet lock.  3. Turn the magnet lock to the left so that the 6 magnets rotates.  4. Input the white field pattern signal.  5. Perform magnetic erasing of the CRT with a demagnetizer.  6. Set the brightness and contrast to slightly higher levels, and perform warm-up roughly for 20 - 30 minutes.  ADJUSTING STEP  1. By turning the G CUTOFF VR on the CRT SOCKET PC BOARD fully in clockwise direction and the R and B CUTOFF VR fully in counterclockwise direction, adjust the SCREEN VR to make the green screen visible.  2. After loosening the clamp screw of the deflecting yoke, pull the yoke fully backward, and let color shading appear in a vertical belt form.  3. Pile up the clicks of the two purity magnets alternately each other, and set them to a horizontal position as an initial.  4. While opening and closing or turning the clicks of the two purity magnets, perform adjustment so that the green vertical belt appears at the center of the screen.  5. By pushing out the deflecting yoke to the front side, position the yoke so that the entire screen becomes totally green (In, this case, tentatively fix the deflecting yoke with a wedge so that the yoke is not moved).  6. Set the traverse one line SET UP switch to the SET UP side to display traverse one line on the screen.  With the deflecting yoke, make the traverse one line horizontal and further close to the vertical center (Do not change the cross position of the deflecting yoke)	Align the two purity magnets to a horizontal level.  Bring the green belt to the center.
	Return the transverse single line SET UP switch to the NORMAL side.     Confirm that the purity has been attained with regard to the red, blue and monocolor rasters.	Vertical center position

## ADJUSTMENT OF STATIC CONVERGENCE

Adjustment Part	Description	Remarks
CONVERGENCE	<ol> <li>ADJUSTING STEP</li> <li>Input the cross hatch signal.</li> <li>Overlap the red and blue lines at the center of the screen with 4-pole magnet to turn the color to Magenta color (red/blue).</li> <li>Next, overlap the Magenta color (red/blue) and green lines at the center of the screen with 6-pole magnet.</li> <li>Repeat the Steps 2 and 3, and adjust the convergence of the vertical and horizontal lines at the center of the screen.</li> </ol>	Open the two thumbscrews.  Turn together while maintaining the angle of the thumbscrews.

#### **ADJUSTMENT OF DYNAMIC CONVERGENCE**

Adjustment Part	Description	Remarks
	<ol> <li>ADJUSTING STEP</li> <li>Remove the wedge with which the deflecting yoke was temporarily fixed.</li> <li>Oscillating the deflecting yoke up and down, set a convergence of points, L, R, T and B, on the screen and temporarily fix it with a wedge.</li> <li>Maintaining that situation, oscillate the deflecting yoke right and left and set the convergence of points, L, R, T and B, on the screen.</li> <li>Repeating 2 and 3, fix the position of the deflecting yoke with three wedges so as to produce the best condition for the convergence of points L, R, T and B, on the screen.</li> </ol>	(FRONT VIEW)  TRED GREEN BLUE GREEN RED Tilting the yoke upward will move the lines as shown with the arrows.  (FRONT VIEW)  GREEN RED RED RED RED GREEN RED RED GREEN RED RED GREEN RED RED GREEN RED RED Tilting the yoke to the right will move the lines as shown with the arrows.

## AFTER COMPLETION OF PURITY-CONVERGENCE ADJUSTMENT

Adjustment Part	Description	Remarks
	Fasten the clamp screw of the deflecting yoke tightly.     Coat the six magnets and magnet lock with lerchlock.     Lerchlock Type name No. 3-C NET 200g (Manufacturer-Raihiden Kagaku Kabushikigaisha)     Coat silicon on the three wedges.     Silicon Type name KE4866 NET 100g (Shinetsu Kagaku)	

# **PARTS LIST**

part No. indicated according to (NOTE 2).

## **CAUTION**

- The module circuit board is supplied together with the assembly, but the parts which do not have the drawing in this Parts List, P. C. Board Ass'y and the Parts No. columns of which are filled with lines . will not be supplied.
- As a rule, the resistors and capacitors which are indicated as shown in (NOTE 2) "HOW TO EXPRESS PARTS NUMBERS OF STANDARD PARTS" are not shown in the list of the parts on the board.


  When ordering the service parts, confirm the resistance/rated power, capacitance/rated voltage, and type of the parts, then order by the

## ( NOTE 1 ) ABBREVIATIONS OF RESISTORS, CAPACITORS AND TOLERANCES

	RESISTORS		CAPACITORS
CR	Carbon Resistor	C CAP.	Ceramic Capacitor
FR	Fusible Resistor	E CAP.	Electrolytic Capacitor
PR	Plate Resistor	м САР.	Mylar Capacitor
V R	Variable Resistor	HV CAP.	High Voltage Capacitor
HV R	High Voltage Resistor	MF CAP.	Metalized Film Capacitor
MFR	Metal Film Resistor	MM CAP.	Metalized Mylar Capacitor
MG R	Metal Glazed Resistor	MP CAP.	Metalized Polystyrol Capacitor
MP R	Metal Plate Resistor	PP CAP.	Polypropylene Capacitor
OM R	Metal Oxide Film Resistor	PS CAP.	Polystyrol Capacitor
CMF R	Coating Metal Film Resistor	TF CAP.	Thin Film Capacitor
UNF R	Non-Flammable Resistor	мрр Сар.	Metalized Polypropylene Capacitor
CH V R	Chip Variable Resistor	TAN. CAP.	Tantalum Capacitor
CH MG R	Chip Metal Glazed Resistor	CH C CAP.	Chip Ceramic Capacitor
COMP. R	Composition Resistor	BP E CAP.	Bi-Polar Electrolytic Capacitor
LPTC R	Linear Positive Temperature Coefficient Resistor	CH AL E CAP.	Chip Aluminum Electrolytic Capacitor
	· · ·	CH AL BP CAP.	Chip Aluminum Bi-Polar Capacitor
		CH TAN. E CAP.	Chip Tantalum Electrolytic Capacitor
		CH AL BP E CAP.	Chip Tantalum Bi-Polar Electrolytic Capacitor

	TOLERANCES								
F	F G J K M N R H Z P								
±1%	±2%	±5%	± 10%	± 20%	± 30%	+30%	+50%	+80%	+ 100%

## (NOTE 2) HOW TO EXPRESS PARTS NUMBERS OF STANDARD PARTS



## MAIN PARTS LIST


SYMBOL NO,	Δ	PART NO.	PART NAME	REMARKS
CRT & TUNE	Δ	CE40266-00A CJ27569-00A CELD023-001 A22JCM00X-AQ	P. C. MAGNET DEF YOKE ASSY DEG COIL PICTURE TUBE	
VARIABLE R R1338 R1351 R1814 R1816 R2425		QVPC611-202HZ QVPC611-203HZ QVPC611-104HZ QVPC611-104HZ QVPE605-501H	V R (DL LEVEL) V R (PAL SUB CHRO V R (NORMAL FF PU V R (P/C FF PULSE TRIM RESISTOR	LSE PHASE) 100kΩ
R 2 4 2 6 R 2 4 2 7 R 2 4 3 3 R 2 5 2 6 R 2 5 5 0		QVPE605-102H QVPE605-501H QVPCA02-501H QVPC611-502HZ QVPE605-103H	TRIM. RESISTOR TRIM. RESISTOR V R (V. CENTER) V R (H. HOLD) TRIM. RESISTOR	(V. HEIGHT UNDER) (V. LIN.) 500 Ω 5kΩ (H. POSITION)
R 3 7 0 3 R 3 7 0 4 R 3 7 1 3 R 3 7 1 4 R 3 7 2 3		QVPE 8 0 5 - 1 0 3 H QVPE 8 0 5 - 2 0 1 H QVPE 8 0 5 - 1 0 3 H QVPE 8 0 5 - 2 0 1 H QVPE 8 0 5 - 1 0 3 H	V R (R CUTOFF) V R (R DRIVE) V R (G CUTOFF) V R (G DRIVE) V R (B CUTOFF)	10 k Ω 200 Ω 10 k Ω 200 Ω 10 k Ω
R 4 1 0 1 R 4 1 0 3 R 4 1 0 9 R 4 1 2 0 R 4 1 2 1		QVAZOO6-C010A QVPC611-103HZ QVPC611-202HZ QVPC611-502HZ QVPC611-103HZ	V R (CONT. BRIGHT V R (SUB CONTRAST V R (SUB BRIGHT) V R (V. HOLD) V R (SUB CHROMA)	
R 9 9 1 9 R 9 9 2 5		QVPC611-501HZ QVPC611-203HZ	V R (B1 ADJ) V R (BATTERY PROT	500 Ω ECTOR) 20kΩ
FUSIBLE R R2778 R9935	Δ Δ	L	F R F R	15 Ω
TRANSFORME T9901		CE41929-00A CE41915-00B	FLYBACK TRANSF SWITCHING TRANSF	
D I O D E D I 2 I I D 2 5 0 2 D 2 5 0 9 D 2 7 7 1 D 4 I 0 4	Δ	MA 4 0 8 2 (L) -T 2 DFA 1 A 4 - 4 MA 4 2 0 0 (M) -T 2 HZ 7 B 2 L - C 1 SML 1 2 1 6 W	ZENER DIODE SI. DIODE ZENER DIODE ZENER DIODE LE D 2 (G+R)	
D 9 9 0 1 D 9 9 0 5 D 9 9 0 6 D 9 9 0 7 D 9 9 0 9	Δ	LB-156-LFB FML-G12S RD6. 2ES (B3) -T2 ESAB82M-004 RD5. 6ES (B3) -T2	DIODE BRIDGE SI DIODE ZENER DIODE S B DIODE ZENER DIODE	
TRANSISTO Q2508 Q3701 Q3702 Q3703	R	2 SC 2 7 4 9 (N-K) 2 SC 2 6 1 1 2 SC 2 6 1 1 2 SC 2 6 1 1	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
I C I C 1 2 0 1 I C 1 2 0 2 I C 1 3 0 1 I C 1 8 0 1 I C 1 8 0 2		AN 5 6 1 5 TC 4 0 6 6 B P AN 5 6 2 5 N TC 4 0 6 6 B P TC 4 5 3 8 B P	I. C. I. C. (M) I. C. I. C. (M) I. C. (M)	
1 C 1 8 0 3 1 C 2 4 0 1	1	TC4538BP AN5515	I. C. (M) I. C. (M)	


SYMBOL	Δ	PART NO.	PART NAME	REMARKS
NO.  I C  I C 2 4 0 2  I C 2 5 0 1  I C 2 5 0 2  I C 2 5 0 3  I C 2 5 0 5	Δ	TC4538BP HA11423 TC4538BP TC4066BP TA78012AP	I. C. (M) I. C. I. C. (M) I. C. (M) I. C. (M)	
1 C 2 6 0 1 1 C 6 2 0 1 1 C 6 6 0 1 1 C 9 9 0 1 1 C 9 9 0 2	Δ.	AN 5 2 6 5 LA 7 0 1 6 TC 4 0 6 6 B P STR 1 0 0 0 6 - A AN 5 9 0 0	I. C. (M) I. C. I. C. (M) I. C. (H) I. C. (M)	
I C 9 9 0 3 I C 9 9 0 4		UPC4558C TA78012AP	I. C. I. C. (M)	
FUSE F9901 F9902	<u>∧</u>		FUSE FUSE	2. 5 A 4 A
OTHERS	<u></u>	CM22138-A0A CM11826-A01 QZF2207-001 CM11827-A0A QMCB005-001	INPUT PANEL ASSY TOP COVER FOOT FRONT PANEL ASSY 3P INLET	× 4
DL 1 2 0 1 DL 1 3 0 2	Δ <u>Λ</u>	SBX-S005A	4P CONNECTOR SECAM MODULE POWER CORD DELAY LINE DELAY LINE	
DL1303 LF9901 LF9902 RY2501 RY9901		CE41094-00B CESK006-001	1H DELAY LINE LINE FILTER LINE FILTER RELAY RELAY	
S 2 5 0 1 S 4 1 0 1 S 4 1 0 2	Δ	HSA0899-01D QSP4Z01-C01 QSL4A13-C02 QSTL435-C01 QSTL435-C01	CONE SPEAKER PUSH SWITCH LEVER SWITCH PUSH SWITCH PUSH SWITCH	H. CENTER SW
S 6 2 0 1 S 6 2 0 2 S 6 2 0 3 S 6 2 0 4 S 6 5 0 1 T H 9 9 0 1 X 1 3 0 1	<u></u>	QSS4C22-C02 QSS4C22-C02 QSS4C22-C02 QSS4C22-C03 QSS4C22-C02 A76038-T CE41953-001	SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH POSISTOR CRYSTAL	Termination SW Termination SW Termination SW SET UP SW AFC SW

## **EXPLODED VIEW PARTS LIST**

	SYMBOL NO.	PART NO.	PART NAME	REMARKS
Δ	1 2 3 4 5	CM3 4 7 4 1 - 0 0 1 CM4 6 7 5 8 - A 0 1 CM4 6 7 5 9 - A 0 1 QMCB 0 0 5 - 0 0 1 SSSB 3 0 0 8 Z	CONTROL BASE VOLUME KNOB PUSH KNOB 3P INLET TAPPING SCREW	×4 ×8 ×4
<b>△</b>	6 7 8 9 1 0	CEMR 0 0 4 - 0 0 1 QSP 4 Z 0 1 - C 0 1 CE 4 1 9 2 9 - 0 0 A CM 3 4 7 3 9 - A 0 1 CM 1 1 8 9 7 - A 0 1	4P CONNECTOR PUSH SWITCH FLYBACK TRANSF HVT BASE HVT HOLDER	
Δ Δ Δ	1 1 1 2 1 3 1 4 1 5	CM3 4 8 5 0 - A 0 1 A 2 2 J CM 0 0 X - A Q CEL D 0 2 3 - 0 0 1 CJ 2 7 5 6 9 - 0 0 A CH 3 0 4 4 2 - 0 0 A	HVT COVER PICTURE TUBE DEG COIL DEF YOKE ASSY BRAIDED ASSY	
	1 6 1 7 1 8 1 9 2 0	CH 4 1 9 8 7 - 0 0 A CE 4 0 2 6 6 - 0 0 A CE 4 0 6 6 6 - 0 0 A QZ F 2 2 0 7 - 0 0 1 GBSB 3 0 0 8 Z	BRAIDED SUB ASSY P. C. MAGNET WEDGE FOOT TAPPING SCREW	×3 ×4 ×4
	2 1 2 2 2 3 2 4 2 5	CM34735-001 CM34851-001 SBSF3008Z CM46755-001 SBSF3008Z	GUIDE RAIL GUIDE RAIL TAPPING SCREW SLIDER TAPPING SCREW	× 6
	2 6 2 7 2 8 3 0 3 1	CM 2 2 1 4 1 - 0 0 1 CM 4 4 2 8 6 - 0 0 A H S A 0 8 9 9 - 0 1 D CM 2 2 1 3 8 - A 0 A CM 4 6 7 6 2 - 0 0 1	BOTTOM COVER SCREW CONE SPEAKER INPUT PANEL ASSY GUARD	× 6 × 2
	3 2 3 3 3 4 3 5 3 6	NNS3000Z CEMR002-001 CEMR003-001 CM11826-A01 CM44286-00E	NUT 7P CONNECTOR 7P CONNECTOR TOP COVER ASSY SCREW	×4 Y/C358 OUT Y/C358 IN ×12
	3 7 3 9 4 0 4 1 4 2	CM22092-A01 SDSA3008M CM34744-001 (R) PU46361-2 PU46385-3	REAR COVER SCREW ROLL R LABEL HANDLE HANDLE COVER	× 2
	4 3 4 4 4 5 1 0 0 1 0 1 1 0 2 1 0 3	SHSP4012R NFS4000Z CM46754-001 CM11827-A0A CM34740-A01 CM46756-A01 CM46757-001	SCREW NUT SLIDE HOLDER FRONT PANEL ASS CONTROL SHEET POWER KNOB SPRING	×2 ×2 Include No. 101~106
	1 0 4 1 0 5 1 0 6	CM46803-001 NFS3000Z CM46941-001	GUARD NUT EARTH PLATE	× 2

## **EXPLODED VIEW**





## PRINTED CIRCUIT BOARD PARTS LIST

SIGNAL PC BOARD ASS'Y (FX-1026A)

SYMBOL NO.	PART NO.	PART NAME	REMARKS
VARIABLE R R1338 R1351 R1814 R1816	QVPC611-202HZ QVPC611-203HZ QVPC611-104HZ QVPC611-104HZ	V R (DL LEVEL) V R (PAL SUB CHRO V R (NORMAL FF PU V R (P/C FF PULSE	LSE PHASE) 100kΩ
CAPACITOR C1215 C1236 C1240 C1241 C1242	QAT3710-300MZ QETC1CM-337Z QETC1CM-108Z QETC1CM-108Z QETC1CM-337Z	TRIM CAPACITOR E CAP. E CAP. E CAP. E CAP.	330 µF 16V M 1000 µF 16V M 1000 µF 16V M 330 µF 16V M
C 1 2 4 3 C 1 3 0 8 C 1 3 0 9 C 1 3 1 1 C 1 3 1 4	QETC1CM-337Z QCT25CH-120Z QAT3710-300MZ QFV71HJ-563MZ QEN61HM-474Z	E CAP. C CAP. TRIM CAPACITOR TF CAP. BP E CAP.	330 µF 16V M 12 pF 0.056 µF 50V J 0.47 µF 50V M
C 1 3 2 8 C 1 3 3 2 C 1 3 4 1 C 1 3 4 3 C 1 8 0 2	QAT3710-300MZ QAT3710-300MZ QAT3710-300MZ QAT3710-300MZ QFV71HJ-104MZ QCT25CH-121Z	TRIM CAPACITOR TRIM CAPACITOR TRIM CAPACITOR TF CAP. C CAP.	0. 1μF 50V J 120pF 50V J
C 1 8 0 3 C 1 8 0 4 C 1 8 0 5	QCT25CH-220Z QCT25CH-151Z QCT25CH-101Z	C CAP. C CAP. C CAP.	22pF 50V J 150pF 50V J 100pF 50V J
TRANSFORME T1302	CE40394-001	B P TRANSF	
COIL L1202 L1203 L1302 L1303 L1304	A 7 6 1 8 6 - 1 8 Z A 7 6 1 8 6 - 1 2 Z A 7 6 1 8 6 - 8. 2 Z A 7 6 1 8 6 - 8. 2 Z A 7 6 1 8 6 - 8. 2 Z A 7 6 1 8 6 - 3 9 Z	PEAKING COIL PEAKING COIL PEAKING COIL PEAKING COIL PEAKING COIL	18 µH 12 µH 8.2 µH 8.2 µH 39 µH
L 1 3 0 5 L 1 3 0 6	A 7 6 1 8 6 - 4. 7 Z A 7 6 1 8 6 - 2. 2 Z	PEAKING COIL PEAKING COIL	4. 7 μH 2. 2 μH
D I ODE D1 2 0 5 D1 2 0 6 D1 2 0 7 D1 2 1 0 D1 2 1 1	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 1 S S 1 4 6 - T 2 1 S S 1 3 3 - T 2 MA 4 0 8 2 (L) - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE ZENER DIODE	
D1212 D1301 D1302 D1303 D1304 D1305	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
D1306 D1307 D1308 D13090 D1801	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
TRANSISTO Q1204 Q1207 Q1208 Q1209 Q1211	R 2 SC1740S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Q1212	2 S C 1 7 4 0 S (QR) -T	SI. TRANSISTOR	

SYMBOL NO.	PART NO.	PART NAME	REMARKS
TRANSISTOR Q1213 Q1214 Q1215 Q1217 Q1218	2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S A 9 3 3 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Q1219 Q1220 Q1221 Q1304 Q1305	2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Q 1 3 0 6 Q 1 3 0 8 Q 1 3 1 0 Q 1 8 0 1 Q 1 8 0 2	2 SA 9 3 3 S (QR) -T 2 SC 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Q1803 Q1804 Q1805 Q1806 Q1807	2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
1 C 1 C 1 2 0 1 1 C 1 2 0 2 1 C 1 3 0 1 1 C 1 8 0 1 1 C 1 8 0 2	AN 5 6 1 5 TC 4 0 6 6 BP AN 5 6 2 5 N TC 4 0 6 6 BP TC 4 5 3 8 BP	I. C. I. C. (M) I. C. I. C. (M) I. C. (M)	
101803	TC4538BP	I. C. (M)	
OTHERS  DL 1 2 0 1 DL 1 3 0 2 DL 1 3 0 3	CHA101N-24P-M SBX-S005A CE41679-001 CE41042-002 CE41489-001	MHI CONNECTOR SECAM MODULE DELAY LINE DELAY LINE 1H DELAY LINE	
X 1 3 0 1	CE41953-001	CRYSTAL	

DEF. PC BOARD ASS'Y (FX-2006A)

	SYMBOL NO.	PART NO.	PART NAME	REMARKS
	VARIABLE R R2425 R2426 R2427 R2433 R2526	QVPE605-501H QVPE605-102H QVPE605-501H QVPCA02-501H QVPCA011-502HZ	TRIM. RESISTOR TRIM. RESISTOR TRIM. RESISTOR V R (V. CENTER) V R (H. HOLD)	(V. HEIGHT NORMAL) (V. HEIGHT UNDER) (V. LIN.) 500 Ω 5 kΩ
	R 2 5 5 0	QVPE605-103H	TRIM, RESISTOR	(H. POSITION)
Δ	FUSIBLE R R2778	QRZ0054-4R7M	F R	
Δ	RESISTOR R2429 R2435 R2529 R2531 R2540	QRX019J-5R6S QRX019J-1R2S QRD123J-101SX QRG019J-121S QRG019J-102S	MF R MF R C R OM R OM R	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
	R 2 5 4 3 R 2 5 4 4 R 2 5 4 5 R 2 5 4 7 R 2 5 5 8	QRG019J-221S QRG019J-680S QRG019J-182S QRX019J-1R2S QRX019J-4R7S	OM R OM R OM R MF R MF R	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$
Δ	R 2 6 0 6 R 2 7 7 1 R 2 7 7 2	QRG039J-180A CJ39520-00N QRD161J-223Y	OM R RESISTOR ARRAY C R	18 Ω 3W J 22kΩ 1/6W J
	CAPACITOR C2408 C2410 C2424 C2507 C2509	QEE61VK-105BZ QETC1CM-227Z QEN62AM-474Z QFV71HJ-224MZ QCT25CH-181Z	TAN. CAP. E CAP. BP E CAP. TF CAP. C CAP.	1 μF 35 V K 2 2 0 μF 16 V M 0. 4 7 μF 10 0 V M 0. 2 2 μF 50 V J 180 pF 50 V J
Δ	C 2 5 1 1 C 2 5 1 3 C 2 5 1 7 C 2 5 2 4 C 2 5 2 5	QCT25CH-271M QFP31HJ-332S QFZ0083-563MZ QEM61HK-225MZ QFP42JJ-682M	C CAP. PP CAP. MY CAP. E CAP. PP CAP.	270pF 50V J 3300pF 50V J 0.056µF 2.2µF 50V K 6800pF 630V J
Δ Δ	C 2 5 2 7 C 2 5 2 8	QFP42JJ-682M QFP42JJ-682M QFP42JJ-682M QFP42JJ-822M QFP42JJ-822M QEM61HK-225MZ	PP CAP. PP CAP. PP CAP. PP CAP. E CAP.	6800pF 630V J 6800pF 630V J 6800pF 630V J 8200pF 630V J 2.2 \( \mu \) F 50V K
	C 2 5 3 1 C 2 5 3 2 C 2 5 3 5 C 2 5 3 6 C 2 5 4 1 C 2 5 4 2 C 2 5 4 5	QETC 2 CM-1 0 5 Z QFK 6 2 A J - 3 3 5 M QFV 7 1 H J - 4 7 4 M Z QFV 7 1 H J - 4 7 4 M Z QFV 7 1 H J - 2 2 4 M Z QETB 2 EM-3 3 6 QFV 7 1 H J - 4 7 4 M Z	E CAP. MM CAP. TF CAP. TF CAP. TF CAP. TF CAP. E CAP. TF CAP.	1 \( \mu \) F \\ 3. \( 3 \mu \) F \\ 10. \( 47 \mu \) F \\ 5. \( 47 \mu \) F \\ 5. \( 0 \) Y \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 22 \mu \) F \\ 3. \( 3 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \\ 5. \( 0 \) V \\ J \\ 0. \( 47 \mu \) F \
	C 2 6 0 5 C 2 6 0 6	QFV71HJ-104MZ QFV71HJ-104MZ	TF CAP. TF CAP.	0. 1 µF 5 0 V J 0. 1 µF 5 0 V J
Δî	TRANSFORM T2502	E R A 7 6 5 6 8 - M A	H DRIVE TRANSF	1.
<u> </u>	L 2503	CE 4 0 2 2 2 - 0 0 1 CE 4 1 1 9 7 - 0 0 C CJ 3 0 0 3 0 - 0 3 8 CJ 3 0 0 3 0 - 0 3 8	LIN. COIL WIDTH COIL HEATER CHOKE HEATER CHOKE	

Γ	SYMBOL NO.	PART NO.	PART NAME	REMARKS
	D 1 O D E D 2 4 0 1 D 2 4 0 2 D 2 4 0 3 D 2 4 0 4 D 2 5 0 1	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 DF A 1 A 4 - T 3 1 S R 3 5 - 1 0 0 A - T 2 1 S S 1 3 3 - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
	D 2 5 0 2 D 2 5 0 3 D 2 5 0 4 D 2 5 0 5 D 2 5 0 6	DFA1A4-4 DFA1A4-T3 DFA1A4-T3 DFA1A4-T3 DFA1A4-T3	SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
<b>A</b>	D 2 5 0 8 D 2 5 0 9 D 2 7 7 1 D 2 7 7 2 D 2 7 7 3	1 S S 1 3 3 - T 2 MA 4 2 0 0 (M) - T 2 H Z 7 B 2 L - C 1 1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2	SI. DIODE ZENER DIODE ZENER DIODE SI. DIODE SI. DIODE	
	D 2 7 7 4 D 2 7 7 5 D 2 7 7 6 D 2 7 7 7 D 2 7 7 8	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 DF A 1 A 4 - T 3 1 S S 1 4 6 - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
	D2779 D2780	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2	SI. DIODE SI. DIODE	
	TRANSISTO Q2401 Q2402 Q2403 Q2501 Q2502	R 2 SC1740S (QR) -T 2 SA933S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
	Q2503 Q2504 Q2505 Q2506 Q2507	2 S A 9 3 3 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T 2 S C 1 6 2 7 A (Y) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Δ	Q2508 Q2509 Q2511 Q2771	2 SC 2 7 4 9 (N-K) 2 SC 1 7 4 0 S (QR) -T 2 SC 1 7 4 0 S (QR) -T 2 SC 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Δ	I C I C 2 4 0 1 I C 2 4 0 2 I C 2 5 0 1 I C 2 5 0 2 I C 2 5 0 3 I C 2 5 0 5 I C 2 6 0 1	AN 5 5 1 5 TC 4 5 3 8 B P HA 1 1 4 2 3 TC 4 5 3 8 B P TC 4 0 6 6 B P TA 7 8 0 1 2 A P AN 5 2 6 5	I. C. (M) I. C. (M) I. C. I. C. (M) I. C. (M) I. C. (M) I. C. (M)	
Δ	OTHERS RY2501 S2501	CHA101N-24R-M CESK006-001 QSL4A13-C02	MHI CONNECTOR RELAY LEVER SWITCH	×2 H. CENTER SW

## CRT SOCKET PC BOARD ASS'Y (FX-3017A)

SYMBOL NO.	PART NO.	PART NAME	REMARKS
VARIABLE R R 3 7 0 3 R 3 7 0 4 R 3 7 1 3 R 3 7 1 4 R 3 7 2 3	QVPE805-103H QVPE805-201H QVPE805-103H QVPE805-201H QVPE805-103H	V R (R CUTOFF) V R (R DRIVE) V R (G CUTOFF) V R (G DRIVE) V R (B CUTOFF)	10 k Ω 200 Ω 10 k Ω 200 Ω 10 k Ω
RESISTOR R 3 7 0 6 R 3 7 0 7 R 3 7 1 6 R 3 7 1 7 R 3 7 2 6	QRG019J-822S QRZ0039-332 QRG019J-822S QRZ0039-332 QRG019J-822S	OM R COMP. R OM R COMP. R OM R	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
R 3 7 2 7	QRZ0039-332	COMP. R	3.3kΩ 1∕2W K
CAPACITOR C3751 C3752 C3753	QETB2EM-475 QETC2EM-105Z QCZ0121-102M	E CAP. E CAP. C CAP.	47μF 250V M 1μF 250V M 1000pF
COIL L3701 L3711 L3721 L3751	A 7 6 1 8 6 - 1 5 0 Z A 7 6 1 8 6 - 1 5 0 Z A 7 6 1 8 6 - 1 5 0 Z C J 3 0 0 3 0 - 0 2 4	PEAKING COIL PEAKING COIL PEAKING COIL HEATER CHOKE	150µH 150µH 150µH
DIODE D3701 D3711 D3751	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 RM 2 C - L F A 1	SI. DIODE SI. DIODE SI. DIODE	
TRANSISTOR Q3701 Q3702 Q3703	2 S C 2 6 1 1 2 S C 2 6 1 1 2 S C 2 6 1 1	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
OTHERS	CE41748-001	CRT SOCKET	

# CONTROL PC BOARD ASS'Y (FX-4015A)

SYMBOL NO.	PART NO.	PART NAME	REMARKS
VARIABLE R R4101 R4103 R4109 R4120 R4121	QVAZ006-C010A QVPC611-103HZ QVPC611-202HZ QVPC611-502HZ QVPC611-103HZ	V R (CONT. BRIGHT V R (SUB CONTRAST V R (SUB BRIGHT) V R (V. HOLD) V R (SUB CHROMA)	
CAPACITOR C4101 C4103	QEKC1CM-107MZ QEKC1CM-107MZ	E CAP. E CAP.	100 µF 16V M 100 µF 16V M
DIODE D4101 D4102 D4103 D4104	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 S M L 1 2 1 6 W	SI. DIODE SI. DIODE SI. DIODE L E D 2 (G+R)	
TRANSISTOI Q4101 Q4102 Q4103	2 SC1740S (QR) -T 2 SC1740S (QR) -T 2 SC1740S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
OTHERS S 4 1 0 1 S 4 1 0 2	QSTL435-C01 QSTL435-C01	PUSH SWITCH PUSH SWITCH	

## INPUT PC BOARD ASS'Y (FX-6018A)

SYMBOL NO.	PART NO.	PART NAME	REMARKS
CAPACITOR C6201 C6202 C6203 C6204 C6205	QEKC1HM-335GMZ QEKC1HM-335GMZ QEKC1CM-336MZ QEKC1CM-336MZ QEKC1CM-107MZ	E CAP. E CAP. E CAP. E CAP. E CAP.	3. 3 \( \mu \text{F} \) 5 0 \( \text{V} \) M 3. 3 \( \mu \text{F} \) 5 0 \( \text{V} \) M 3 3 \( \mu \text{F} \) 1 6 \( \text{V} \) M 3 3 \( \mu \text{F} \) 1 6 \( \text{V} \) M 1 0 0 \( \mu \text{F} \) 1 6 \( \text{V} \) M
C 6 2 1 0 C 6 2 9 9 C 6 6 0 2 C 6 6 0 4 C 6 6 0 5	QEKC1CM-107MZ QFV71HJ-474MZ QEKC1HM-105GMZ QEKC1HM-105GMZ QEKC1CM-107MZ	E CAP. TF CAP. E CAP. E CAP. E CAP.	100 \( \mu \text{F} \) 16 \( \mu \) M \\ 0.47 \( \mu \text{F} \) 50 \( \mu \) J \\ 1 \( \mu \text{F} \) 50 \( \mu \) M \\ 1 \( \mu \text{F} \) 50 \( \mu \) M \\ 100 \( \mu \text{F} \) 16 \( \mu \) M
DIODE D6201 D6202 D6203 D6204	1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2 1 S S 1 3 3 - T 2	SI. DIODE SI. DIODE SI. DIODE SI. DIODE	
TRANSISTOR Q6201 Q6202 Q6203 Q6601 Q6602	2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T 2 S C 1 7 4 0 S (QR) - T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Q6603 Q6604	2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR	
I C I C 6 2 0 1 I C 6 6 0 1	LA7016 TC4066BP	I. C. I. C. (M)	
OTHERS S 6 2 0 1 S 6 2 0 2 S 6 2 0 3 S 6 2 0 4 S 6 5 0 1	QSS4C22-C02 QSS4C22-C02 QSS4C22-C02 QSS4C22-C03 QSS4C22-C03	SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH SLIDE SWITCH	Termination SW Termination SW Termination SW SET UP SW AFC SW
<u> </u> 			

## POWER PC BOARD ASS'Y (FX-9016A)

Γ	SYMBOL NO.	PART NO.	PART NAME	REMARKS
	VARIABLE R R9919 R9925	QVPC611-501HZ QVPC611-203HZ	V R (B1 ADJ) V R (BATTERY PROT	500 Ω ECTOR) 20kΩ
Δ	FUSIBLE R R9935	QRZ0054-150M	FR	15 Ω
	RESISTOR R9901 R9906 R9907 R9909 R9911	QRZ0094-100 QRD123J-473SX QRG029J-101A QRM055K-R33 QRD149J-1R0S	UNF R C R OM R MP R C R	47kΩ 1/2W J 100Ω 2W J 1Ω 1/4W J
	R 9 9 1 2 R 9 9 1 7 R 9 9 2 1 R 9 9 2 3	QRG 0 3 9 J - 5 6 3 A QRG 0 2 9 J - 6 8 1 QRD 1 2 3 J - 2 2 0 S X QRD 1 2 3 J - 3 3 0 S X	OM R OM R C R C R	$\begin{array}{cccccccccccccccccccccccccccccccccccc$
Δ\ Δ\	CAPACITOR C 9 9 0 1 C 9 9 0 2 C 9 9 0 3 C 9 9 0 4 C 9 9 0 7	QFZ9022-224M QCZ9036-472M QCZ9036-222M QCZ9036-222M QFZ9022-224M	MF CAP. C CAP. C CAP. C CAP. M F CAP.	0. 22 µF AC250V M 4700pF AC400V M 2200pF AC400V M 2200pF AC400V M 0. 22 µF
	C 9 9 0 9 C 9 9 1 0 C 9 9 1 1 C 9 9 1 3 C 9 9 1 4	QEZ0084-227R QCZ0122-821U QEHC2AM-106MZ QCF22HP-103M QCZ0122-821U	E CAP. C CAP. E CAP. CH C CAP. C CAP.	220 µF 400V M 10 µF 100V M 0.01 µF 500V P
	C 9 9 1 5 C 9 9 1 6 C 9 9 1 7 C 9 9 1 8 C 9 9 1 9	QFV71HJ-104MZ QEHC1CM-227MZ QEHC1CM-227MZ QEM51VM-477M QEHC1CM-227MZ	TF CAP. E CAP. E CAP. E CAP. E CAP.	0. 1 μF 5 0 V J 2 2 0 μF 1 6 V M 2 2 0 μF 1 6 V M 4 7 0 μF 3 5 V M 2 2 0 μF 1 6 V M
	C 9 9 2 0 C 9 9 2 2 C 9 9 2 3 C 9 9 2 4 C 9 9 2 5	QFV71HJ-474MZ QEM61EK-106MZ QEHB1HM-228M QFV71HJ-474MZ QEHC1HM-336MZ	TF CAP. E CAP. E CAP. TF CAP. E CAP.	0. 47 μF 5 0 V J 10 μF 2 5 V K 2 2 0 0 μF 5 0 V M 0. 47 μF 5 0 V J 3 3 μF 5 0 V M
<u> </u>	C9929	QEHC1CM-337MZ QEH62CM-105MZ QCZ9034-472A QCZ9034-472A QCZ9034-472A	E CAP. E CAP. C CAP. C CAP. C CAP.	330 µF 16V M 1 µF 160V M 4700 pF AC400V P 4700 pF AC400V P 4700 pF AC400V P
Δ	C 9 9 3 1 C 9 9 4 0	QCZ9034-472A QFLB1HK-103M	C CAP. MYLAR CAPACITOR	4700pF AC400V P
⊿i	TRANSFORM T9901 T9902 T9903	E R CE41915-00B A76567-MA CE41916-00A	SWITCHING TRANSF P DRIVE TRANSF CHOPPER TRANSF	
<u> A</u>	DIODE D9901 D9902 D9903 D9904 D9905	LB-156-LFB RU1C-LFA1 EM01 EU2A-LFF4 FML-G12S	DIODE BRIDGE SI. DIODE SI. DIODE SI. DIODE SI. DIODE SI DIODE	
	D 9 9 0 6 D 9 9 0 7 D 9 9 0 8 D 9 9 0 9 D 9 9 1 0	RD6. 2ES (B3) -T2 ESAB82M-004 1SS133-T2 RD5. 6ES (B3) -T2 1SS133-T2	ZENER DIODE S B DIODE SI. DIODE ZENER DIODE SI. DIODE	

	SYMBOL NO.	PART NO.	PART NAME	REMARKS
	DIODE D9911 D9912 D9913	1 S S 1 3 3 - T 2 E U 2 A - L F F 4 R U 1 C - L F A 1	SI. DIODE SI. DIODE SI. DIODE	
	TRANSISTOR Q9901 Q9902 Q9903 Q9904	2 S C 1 6 2 7 A (Y) -T 2 S C 2 7 5 0 (MLK) 2 S C 1 7 4 0 S (QR) -T 2 S C 1 7 4 0 S (QR) -T	SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR SI. TRANSISTOR	
Δ	I C I C 9 9 0 1 I C 9 9 0 2 I C 9 9 0 3 I C 9 9 0 4	STR10006-A AN5900 UPC4558C TA78012AP	I. C. (H) I. C. (M) I. C. I. C. (M)	
Δ	FUSE F9901 F9902	QMF 5 1 E 2 - 2 R 5 S QMF 5 1 E 2 - 4 R 0 S	FUSE FUSE	2. 5 A 4 A
Δ	RY9901	CE41094-00B CE41094-00B CESK006-002 A76038-T	LINE FILTER LINE FILTER RELAY POSISTOR	·


## **MODULE PC BOARD PARTS LIST**

The following module pc boards are supplied as assemblies.

The component parts on the module PC boards are available only when the parts are listed in the "MODULE PRINTED CIRCUIT BOARD PARTS LIST".

SECAM MODULE PC BOARD Ass'y (SBX-S005A) within SIGNAL PC BOARD ASS'Y.

## **PACKING**



## **PACKING PARTS LIST**

SYMBOL NO.	PART NO.	PART NAME	REMARKS
1 2 3 4 5	QPGA012-03005 CP30043-004 CP10996-A0A CP10704-010 QMP4718-200R	POLY BAG SET COVER CUSHION PACKING CASE POWER CORD	
6 8	TM-1000PS-IB-A CM22200-001	INST BOOK X-RAY CARD	

# TM-1000PS

# **SCHEMATIC DIAGRAM**

#### ■ NOTICE

The voltage reading and waveform are measured at each point with a multi-meter and an oscilloscope while input a video signal (colour bar) through the video input terminal (INPUT A) on the monitor.

The measurements were made with each VR under the condition just after the shipment. The figures of the signal circuits may be more or less different after adjustments, so use the figures simply for reference.

Multimeter used

Н

DC 20 kΩ/V

Given figures are all DC voltages.

Sweep speed of osciloscope

⇒20µS/div

V ⇒5mS/div

Others ⇒Sweeping time is indicated

Since the schematic diagram is a standard one, the circuit and circuit constants may be subject to change for improvement without any notice.

#### SAFETY

FR ( $\mbox{\begin{tabular}{l} \begin{tabular}{l} \$ 

As to other parts too, use designated parts to maintain safety and performance.

## ■ INDICATION OF PARTS SYMBOL

Inside board (Example) FX-1026A : R1209⇒R209

## ■ CIRCUIT DIAGRAM DISPLAY SYMBOLS

#### 1. Resistor

Resistance value

When no unit is provided :  $[\Omega]$ 

 $K : [k\Omega]$  $M : [M\Omega]$ 

• Rated permissible power capacity

When no display is made: 1/6 [W] Others: Display are provided

Type

Without indication : Carbon resistor

OMR : Oxide metal film resistor
UNFR : Non-Flammable resistor
CMF,MFR : Coating metal film resistor

CMF,MFR

FR : Fusible resistor
\*Composition resistor 1/2 [W] is indicated as "1/2S" or

"Comp".

#### 2. Capacitor

Capacitance

Over 1 [pF] Below 1 [µF]

Withstand voltage

No display : DC 50 [V]

Others : DC withstand voltage [V] AC display : AC withstand voltage [V]

• Display of electrolytic capacitor is as follows.

(Example)

47/50⇒Capacity [μF] /withstand voltage [V]

\*NP: Non-polar (or Bipolar) electrolytic capacitor.

Type

No type display indication : Ceramic capacitor

MY : Mylar capacitor

MM : Metalized mylar capacitor
PP : Polypropylene capacitor

MPP : Metalized polypropylene capacitor

NP : Nonpolar electrolytic capacitor
BP : Bipolar electrolytic capacitor

TAN. : Tantalum capacitor

3. Coil

When no unit is displayed: [µH]

#### 4. Power supply

\_\_\_\_\_: B1

\*Respective voltage values are indicated.

#### 5. Test point & GND. symbol

•

: Test point of mini-GP pin

**?**:

: Only test point display

L : LIVE side ground

: NEUTRAL side ground

#### 6. Connecting method

: Connector


0 C


: Wrapping or soldering



- : Receptacle


#### ALIGNMENT LOCATION






POWER PC BOARD FX-9016A

## CRT PC BOARD FX-3017A




## CONTROL PC BOARD FX-4015A




2 (No. 50399)


NO.50399 Sep. 1990




#### NOTE FOR SERVICE -


This model's power circuit is partly different in the GND. The difference of the GND is shown by the LIVE (primary:  $\bot$ ) side GND and the NEUTRAL (secondary: →) side GND. Don't short between the LIVE side GND and NEUTRAL side GND or never measuring apparatus (oscilloscope etc.) the LIVE side GND and NEUTRAL side GND at the same time. If above note will not be kept, a fuse or any parts will be broken.







#### SIGNAL PCB BACK PATTERN






## CONTROL PCB BAK PATTERN







# DEF PCB BACK PATTERN CK11104-B01-1 G3 DUMP DUMP 10 COL 9 L503 **300** L504

# CRT SOCKET PCB BACK PATTERN



## POWER PCB BACK PATTERN





## Basing of Transistor & ICs

